Sennheiser SL Bodypack DW Microphone



Green light when fully charged
Red light when charging

Please Return Bodypack to the

